

MAXIMUM BIKE /EIGHT CAPACITY

25 kg




Transformer™ Stand DX fits most bikes, however, it will not work with bikes that do not have seatstays or chainstays.



DO NOT use on grass, loose dirt, gravel, uneven or soft surfaces. Check the stability of the Transformer™ Stand DX periodically to insure safe storage of your bikes.




Avoid bodily harm when folding support legs.




## **OPERATING INSTRUCTIONS**

1 Use the QR locking lever to open or close the support legs completely.




2 Close hook and slide to adjust to proper height. Open hook to lock in position.




## QUICK START TO USE TUNE-UP STAND FUNCTION

Place Transformer™ Stand DX next to your bike. Adjust the height of each Folding Hook as shown keeping a height difference of 3 cm between Folding Hook and seatstay/ chainstay.



Lift bike onto Folding Hooks then fine tune height adjustment as necessary.







## WARRANTY

2-year Warranty: All mechanical components against manufacturer defects only.

Warranty Claim Requirements
To obtain warranty service, you must have your original sales receipt. Items returned without a sales receipt will assume that the warranty begins on the date of manufacture. All warranties will be void if the product is damaged due to user crash, abuse, system alteration medification or used in any ways not alteration, modification, or used in any way not intended as described in this manual.

\* The specifications and design are subject to change without notice.

Please contact your Topeak dealer with any questions. For USA customer service, call: 1-800-250-3068

M-TTF-SD02 EN 08/16 Copyright © Topeak, Inc. 2016